

Measuring instructions

Please use a metal tape as cloth tapes have a tendency to stretch, and accurate sizes are essential.

Inside Recess

Measure recess width and drop in several places making allowances for any protrusions, i.e. tiles skirting, catches etc. and give us the smallest dimension in both cases, stating **RECESS SIZE** we will allow the working tolerances.

Outside recess

Decide how much you wish to overlap the recess and state the overall width and drop as **CLOTH SIZE**.

WHEN ORDERING YOUR BLIND PLEASE STATE:

1. TYPE OF BLIND-
(i.e Customer's Own Fabric Roller Blind)
2. FABRIC NAME OF YOUR FABRIC
3. CONTROL
R/H Rollacord side action is standard. Please specify if L/H control is required or the alternative string Roller System. (please note if a spring roller is required it will feature a wooden acorn as standard)
4. If you require a Rollacord blind, the side control unit together with the chain, weight and bracket covers supplied will be white as standard.
5. Finish
Clearly state if Standard Finish, Shaped Finish (please specify) or Turret Finish (please specify) is required.
6. Exact sizes
Advise width first in metric (mm) or imperial (ft.ins.) measurements, stating whether **RECESS SIZE** or **CLOTH WIDTH** . Also advise on drop required.

When deciding whether to fit the blind inside or outside the recess, **please note:**

If the recess is less than 64mm (2 1/2") deep, the window opens inwards, or there are other obstructions it will be necessary to fit the blind outside the recess.

When fitting outside the recess, the suggested overlap is 75mm (3") each side, top and bottom. When measuring for blinds outside the recess, please remember the difference between pin width and cloth width as shown in the diagrams.

